CREATING YOUR OWN FAMILIES

## REVIEW

Companies want to control how their parts and assemblies are named, and this is easily done in ASD. Companies can easily customize ASD so that the parts and assemblies are named the way they want them to be. To do this go to:

ASD-Drawings > Settings > **Project preferences...**

This brings up the Project Preferences dialog box.

Select the **Families settings...** button, this will bring up the Family Manager dialog box:

For this example, let's look at adding a new family for Bracing using the prefix of BR.

Select the [New] button in the top right corner of the Family Manager dialog box.

Note, for the information added below, we had previously created a layer named RBCS_Bracing:

Details	
Name	Bracing
Layer	RbCS_Bracing
Part type	Profile
Color	ByLayer
Default single part position prefix	br
Default main part position prefix	BR

Select the [OK] followed by the [OK] to save and finish your new family.

Now when creating new profiles, ensure that they are placed on the correct family so that they are named to the standard that you require.