



Work plane offset from face

Select: A planar face. Click the edge of the face and drag in the direction of the **offset**. Enter a value in the edit box to specify the **offset** distance.

Result: Creates a **work plane** parallel to the selected face at the specified **offset** distance.