

Home Insert Annotate Analyze Structure Massing & Site Collaborate View Manage Modify | Edit Footprint

Select Properties Clipboard Geometry Modify View Measure Create Mode Draw Work Plane Tools

Boundary Line Slope Arrow Set Show Ref Plane Viewer Align Eaves

Modify | Edit Footprint Overhang: Defines Slope:  Extends into wall (to core) Activate Dimensions

Properties

<Sketch> (2) Edit Type

Constraints

Specify	Height at Tail
Level of Tail	Default
Height Offset at Tail	0' 0"
Level of Head	Default
Height Offset at Head	1' 0"

Dimensions

Slope	9° / 12°
Length	1' 3"

Identity Data

Design Option	Main Model
---------------	------------

Properties help Apply

Revit Residence2 - Project Browser

- 0\_Views (all)
  - Floor Plans
    - B.O. Footing
    - Basement
    - Ceiling
    - First Floor
    - First Floor Framing
    - Foundation
    - Roof Framing
    - Roof Plan**
    - Second Floor Framing
    - Site Plan
    - T.O. Footing
  - Ceiling Plans
    - Ceiling
    - First Floor
  - 3D Views
    - (3D)
  - Elevations (Building Elevation)
    - East
    - North
    - South

