

Structure verification

Forbidden use of a compatible node or a support in a slave node o
 The load has not been distributed correctly I there are no objects t
 Number of errors:1
 Number of warnings:1

Display
 Errors
 Warnings
 Notes

Verify Close

Highlighting a line with an error message or warning selects objects connected with it.

Panel calculation model

Delete → Shell
 1 way slabs → Slab-File
 Curtain wall → Slab-Rig
 Deck slab (one-way)
 Dwall Panels

Panels
 226

Apply Close Help

