

- OPEN A TABLE WITH EXCEL AND COPY

File Edit View Insert Format Tools Draw Dimension Modify Parametric Window Help Express


Home Isoc Create Ortho View Ortho Views Compass Elevation & Routing Slope Pipe Supports Equipment Visibility View

2D Wireframe Unsaved View Single viewport



Layer Properties Make Current Match Layer Layers

Naviswork Navigator Plugin



- Undo Paste special... Ctrl+Z
- Redo Ctrl+Y
- Cut Ctrl+X
- Copy Ctrl+C
- Copy with Base Point Ctrl+Shift+C
- Copy Link
- Paste Ctrl+V
- Paste as Block Ctrl+Shift+V
- Paste as Hyperlink
- Paste to Original Coordinates
- Paste Special...**
- Delete Del
- Select All Ctrl+A
- OLE Links...
- Find...



- PASTE SPECIAL EXCEL TABLE IN AUTOCAD




- PASTE SPECIAL - PASTE LINK - AUTOCAD ENTITIES





	A	B	C	D	E
1	PU-0102 D	TRUCK UNLOADING PUMP	ECPM133619	C-13-5-IU01-02	C19AC83VM
2	PU-0201 A	TRANSFER PUMP FROM OIL TANK	ECPM133619	C-13-5-IU01-02	C19AC83VM
3	PU-0102 A	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01-02	C1AAC81VMA
4	PU-0201 B	TRANSFER PUMP FROM NEW OIL TANK	ECPM133619	C-13-5-IU01-02	C19AC83VM
5	PU-0301 A	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01-02	C19AC83VM
6	PU-0301 B	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01-02	C19AC83VM
7	PU-0102 B	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01-02	C1AAC81VMA
8	PU-0102 C	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01-02	C1AAC81VMA
9	FI-0102B	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
10	FI-0102C	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
11	FI-0102D	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
12	FI-0102A	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009

- EXCEL TABLE IN AUTOCAD DRAWING, OK





PU-0102 D	TRUCK UNLOADING PUMP				
PU-0201 A	TRANSFER PUMP FROM OIL TANK				
PU-0102 A	TRUCK UNLOADING PUMP				
PU-0201 B	TRANSFER PUMP FROM NEW OIL TANK	ECPM133619	-02	C19AC83VM	
PU-0301 A	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	-02	C19AC83VM	545m
PU-0301 B	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	-02	C19AC83VM	
PU-0102 B	TRUCK UNLOADING PUMP	ECPM133606	-02	C1AAC81VMA	
PU-0102 C	TRUCK UNLOADING PUMP	ECPM133606	-02	C1AAC81VMA	
FI-0102B	OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009	
FI-0102C	OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009	
FI-0102D	OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009	
FI-0102A	OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009	

- SCALE TABLE SO THAT IT FITS IN A DRAWING AREA



PU-0102	TRUCK UNLOADING PUMP	ECPM133619	C-13-5-IU01	C19AC83VM					
PU-0201	TRANSFER PUMP FROM OIL TANK	ECPM133619	C-13-5-IU01	C19AC83VM					
PU-0102	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01	C1AAC81VMA					
PU-0201	TRANSFER PUMP FROM NEW OIL TANK	ECPM133619	C-13-5-IU01	C19AC83VM					
PU-0301	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01	C19AC83VM					
PU-0301	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01	C19AC83VM					
PU-0102	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01	C1AAC81VMA					
PU-0102	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01	C1AAC81VMA					
FI-0102B	OIL FEEDING LINE FILTER	ECUMD00401	C-13-5-IU01	020310304610009					
1	FI-0102C	OIL FEEDING LINE FILTER	2	ECUMD00401	-02	020310304610009	3	4	5
	FI-0102D	OIL FEEDING LINE FILTER		ECUMD00401	-02	020310304610009			
	FI-0102A	OIL FEEDING LINE FILTER		ECUMD00401	-02	020310304610009			



- EXCEL TABLE HAS BEEN SCALED, OK



	A	B	C	D	E
1	U-0102			C-13-5-IU01	
2	A	TRUCK UNLOADING PUMP	ECPM133619	-02	C19AC83VM
3	A	TRANSFER PUMP FROM OIL TANK	ECPM133619	-02	C19AC83VM
4	A	TRUCK UNLOADING PUMP	ECPM133606	-02	C1AAC81VMA
5	B	TRANSFER PUMP FROM NEW OIL TANK	ECPM133619	-02	C19AC83VM
6	A	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	-02	C19AC83VM
7	B	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	-02	C19AC83VM
8	A	TRUCK UNLOADING PUMP	ECPM133606	-02	C1AAC81VMA

	A	B	C	D	E
9	C	TRUCK UNLOADING PUMP	ECPM133606	-02	C1AAC81VMA
10		F10102B OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009
11		F10102C OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009
12		F10102D OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009
		F10102A OIL FEEDING LINE FILTER	ECUM000401	-02	020310304610009

- FIT TABLE IN DRAWING AREA WITH TABLE BREAK, SAVE AND CLOSE DRAWING, OK



PU-0102 D	TRUCK UNLOADING PUMP	ECPM133619	C-13-5-IU01 -02	C19AC83VM
PU-0201 A	TRANSFER PUMP FROM OIL TANK	ECPM133619	C-13-5-IU01 -02	C19AC83VM
PU-0102 A	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01 -02	C1AAC81VMA
PU-0201 B	TRANSFER PUMP FROM NEW OIL TANK	ECPM133619	C-13-5-IU01 -02	C19AC83VM
PU-0301 A	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01 -02	C19AC83VM
PU-0301 B	NEW OIL TANK DISCHARGE AND TRANSFER PUMP	ECPM133619	C-13-5-IU01 -02	C19AC83VM
PU-0102 B	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01 -02	C1AAC81VMA

PU-0102C	TRUCK UNLOADING PUMP	ECPM133606	C-13-5-IU01-02	C1AAC81VMA
FI-0102B	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
FI-0102C	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
FI-0102D	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009

ALL DISTANCES SHOWN ARE AP...

FI-0102A	OIL FEEDING LINE FILTER	ECUM000401	C-13-5-IU01-02	020310304610009
REV. No.	DATE			

TITLE:
PROJECT DESCRIPTION:
DRAWING NAME:

- WHEN REOPENING THE SAME DRAWING, TABLE DISPLAYS INCORRECT. BREAKS ARE NOT SCALED AS SAVED BEFORE.