

Drawing Properties [X]

Drawing Settings | Components | Wire Numbers | Cross-References | Styles | Drawing Format

Drawing: C:\ACADESHARED\projects\10161\10161 5kvsgr-r1\10161W601110.dwg

Drawing File

Project: 10161 MVSG

Description 1: U1A: MAIN A 52-187 BKR UPPER DOOR WIRING DIAC [Pick>>]

Description 2: [Pick>>]

Description 3: [Pick>>]

☐ For Reference Only

IEC - Style Designators

Project Code: []

Installation Code: A [Drawing...] [Project...]

Location Code: 1 [Drawing...] [Project...]

Sheet Values

Sheet: 1 😊

Drawing: [] 😞

OK Cancel Help

"SHEET"
DOES
UPDAE
THIS VALUE
AUTOMACALLY WHEN
TITLE
BLOCK
UPDATE IS
RUN

"DWGNAM" DOES
NOT UPDATE
THIS VALUE
AUTOMATICALLY

NOW I CAN USE THIS (AUTOMATICALLY FILLED) VALUE IN MY XREF's

I CAN NOT USE THIS VALUE IN MY XREF's [I WISH THIS VALUE WOULD BE
INHERITED FROM MY FILE NAME WHICH IS ALSO MY DRAWING NUMBER