



## AutoCAD<sup>®</sup> Mechanical 2013

### To Change the Cursor Size

1. Right-click in the drawing area, and choose Options.
2. On the Selection tab, under Pickbox Size, and on the Display tab, under Crosshair Size, move the sliders.

#### Related Tasks

- [To Select Objects](#)
- [To Change Object Selection Settings](#)

#### Related References

- [Commands for Selecting Objects](#)