


The Prospector tree on the left side of the interface shows a hierarchical view of the drawing's content. Under the 'X_PROBASE' folder, the 'Group Plot Styles' folder is expanded, and the 'Plot Style' sub-item is selected and highlighted. Other items in the tree include General, Point, Point Cloud, Surface, Parcel, Grading, Alignment, Profile, Profile View, Superelevation View, Cant View, Sample Line, Section, Section View, Section View Styles, Sheet Styles, Label Styles, Band Styles, Table Styles, Commands, Mass Haul Line, Mass Haul View, Catchment, Pipe Network, Pipe, Structure, and Pressure Network.

To change the "Vertical Major", Edit the "Group Plot Style"

Text for the left axis is shifted inside the limits of the viewport. I find it easiest to use trial and error to get it approximately centered.



Yellow Outline is the limits of the viewport

The 'Group Plot Style - Plot Style' dialog box is open, showing the 'Plot Area' tab. The 'Plot area grid details' section contains the following settings: Horizontal major: 0.5000", Horizontal minor: 0.1000", Vertical major: 7.0000", and Vertical minor: 0.1000". The 'Gap between successive pages' section has a 'Gap' of 30.0000". A 'Preview' window on the right shows a grid with a small drawing in the center. A red arrow points from the 'Vertical major' input field to the preview window.

Vertical Major has been changed from 2.5" to 7"