
STATION 64+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 63+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 63+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 62+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 62+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 61+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 67+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 66+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 66+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 65+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 65+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 64+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 69+50
℄
R/W
R/W
Ex EOP
10" water main
10" water main


STATION 69+00
℄
R/W
Ex EOP
30x19" E.R.C.P.
10" water main
10" water main


STATION 68+92
℄
R/W
Ex EOP
30x19" E.R.C.P.
10" water main
10" water main


STATION 68+50
℄
R/W
Ex EOP
10" water main
10" water main


STATION 68+00
℄
R/W
Ex EOP
10" water main
10" water main


STATION 67+50
℄
R/W
Ex EOP
10" water main
10" water main