

GENERAL SHEET NOTES
REFERENCE KEY NOTES
◇ SHEET KEY NOTES

262413.L08

PANEL: 2V

VOLTAGE / PHASE: 240/120V / 1Ø

POLES: 42

KALC: 10

FED FROM: 240V SWITCHBOARD / BUILDING 4 / ROOM 158

LOCATION: BUILDING 4 / ROOM 123

MAIN BREAKER: 225A CB

BREAKER MOUNTING: BOLTED

BUS RATING: 225 AMP

LOAD DESCRIPTION	VOLT*AMP		TRIP RATING AMPS	CIRCUIT NUMBER	CIRCUIT NUMBER	TRIP RATING AMPS	VOLT*AMP		LOAD DESCRIPTION
	L1	L2					L1	L2	
NORTH ADA DOOR CONTROLLER	500	500	20	1	2	15	10	-	POWER ON INDICATOR LIGHT ON PANEL DOOR
SOUTH ADA DOOR CONTROLLER									
RMS 121A, 121B, 121C & 121D QUAD RECEPTACLE	1440		20	5	6	20	-	-	SPARE
RMS 121, 121C & 121D GENERAL USE RECEPTACLE		1280	20	7	8	20	-	-	SPARE
RMS 121, 121A & 121B GENERAL USE RECEPTACLE		1280	20	9	10	20	-	-	SPARE
RM. 121 WIREMOLD RECEPTACLE		1440	20	11	12	20	-	-	SPARE
RM. 121 COPY MACHINE "A"	1440		20	13	14	20	-	-	SPARE
RM. 121 COPY MACHINE "B"		1440	20	15	16	20	-	-	SPARE
SPARE	-		20	17	18	20	-	-	SPARE
SPARE	-		20	19	20	20	-	-	SPARE
SPARE	-		20	21	22	20	-	-	SPARE
SPARE	-		20	23	24	20	-	-	SPARE
SPARE	-		20	25	26	20	-	-	SPARE
SPARE	-		20	27	28	20	-	-	SPARE
SPARE	-		20	29	30	20	-	-	SPARE
SPARE	-		20	31	32	20	-	-	SPARE
SPARE	-		20	33	34	20	-	-	SPARE
SPARE	-		20	35	36	20	-	-	SPARE
SPARE	-		20	37	38	20	-	-	SPARE
SPARE	-		20	39	40	20	-	-	SPARE
SPARE	-		20	41	42	20	-	-	SPARE
TOTAL LOAD:	4640	4640					10	0	
COMBINED LOAD:	4650	4640							

262413.L04

PANEL: 2T

VOLTAGE / PHASE: 240/120V / 1Ø

POLES: 42

KALC: 10

FED FROM: 240V SWITCHBOARD / BUILDING 4 / ROOM 158

LOCATION: BUILDING 4 / ROOM 101

MAIN BREAKER: 225A CB

BREAKER MOUNTING: BOLTED

BUS RATING: 225A AMP

LOAD DESCRIPTION	VOLT*AMP		TRIP RATING AMPS	CIRCUIT NUMBER	CIRCUIT NUMBER	TRIP RATING AMPS	VOLT*AMP		LOAD DESCRIPTION
	L1	L2					L1	L2	
RM. 126 GENERAL USE RECEPTACLE	900		20	1	2	15	10	-	POWER ON INDICATOR LGT. ON PANEL DOOR
RM. 126 FLOORBOX & TV		360	20	3	4	20	-	-	SPARE
RMS 120, 122 & 124 GENERAL USE RECEPT.	900		20	5	6	20	-	-	SPARE
RM. 124 NORTH RECEPT. WORKBENCH C2		1080	20	7	8	20	-	-	SPARE
RM. 124 SOUTH RECEPT. AT WORKBENCH C2	1080		20	9	10	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C2		1280	20	11	12	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C2	1280		20	13	14	20	-	-	SPARE
RM. 124 NORTH RECEPT. AT WORKBENCH C1	1080		20	15	16	20	-	-	SPARE
RM. 124 SOUTH RECEPT. AT WORKBENCH C1		1080	20	17	18	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C1		1280	20	19	20	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C1	1280		20	21	22	20	-	-	SPARE
RM. 122 NORTH RECEPT. AT WORKBENCH B2	1080		20	23	24	20	-	-	SPARE
RM. 122 SOUTH RECEPT. AT WORKBENCH B2		1080	20	25	26	20	-	-	SPARE
RM. 122 PLUGMOLD AT WORKBENCH B2	1280		20	27	28	20	-	-	SPARE
RM. 122 PLUGMOLD AT WORKBENCH B2		1280	20	29	30	20	-	-	SPARE
RM. 124 TV RECEPTACLE		360	20	31	32	20	-	-	SPARE
RM. 122 TV RECEPTACLE	360		20	33	34	20	-	-	SPARE
SPARE	-		20	35	36	20	-	-	SPARE
SPARE	-		20	37	38	20	-	-	SPARE
SPARE	-		20	39	40	20	-	-	SPARE
SPARE	-		20	41	42	20	-	-	SPARE
TOTAL LOAD:	9180	7740					10	0	
COMBINED LOAD:	9190	7740							

262413.L06

PANEL: 2V

VOLTAGE / PHASE: 240/120V / 1Ø

POLES: 42

KALC: 10

FED FROM: 240V SWITCHBOARD / BUILDING 4 / ROOM 158

LOCATION: BUILDING 4 / ROOM 123

MAIN BREAKER: 225A CB

BREAKER MOUNTING: BOLTED

BUS RATING: 225 AMP

LOAD DESCRIPTION	VOLT*AMP		TRIP RATING AMPS	CIRCUIT NUMBER	CIRCUIT NUMBER	TRIP RATING AMPS	VOLT*AMP		LOAD DESCRIPTION
	L1	L2					L1	L2	
NORTH ADA DOOR CONTROLLER	500	500	20	1	2	15	10	-	POWER ON INDICATOR LIGHT ON PANEL DOOR
SOUTH ADA DOOR CONTROLLER									
RMS 121A, 121B, 121C & 121D QUAD RECEPTACLE	1440		20	5	6	20	-	-	SPARE
RMS 121, 121C & 121D GENERAL USE RECEPTACLE		1280	20	7	8	20	-	-	SPARE
RMS 121, 121A & 121B GENERAL USE RECEPTACLE		1280	20	9	10	20	-	-	SPARE
RM. 121 WIREMOLD RECEPTACLE		1440	20	11	12	20	-	-	SPARE
RM. 121 COPY MACHINE "A"	1440		20	13	14	20	-	-	SPARE
RM. 121 COPY MACHINE "B"		1440	20	15	16	20	-	-	SPARE
SPARE	-		20	17	18	20	-	-	SPARE
SPARE	-		20	19	20	20	-	-	SPARE
SPARE	-		20	21	22	20	-	-	SPARE
SPARE	-		20	23	24	20	-	-	SPARE
SPARE	-		20	25	26	20	-	-	SPARE
SPARE	-		20	27	28	20	-	-	SPARE
SPARE	-		20	29	30	20	-	-	SPARE
SPARE	-		20	31	32	20	-	-	SPARE
SPARE	-		20	33	34	20	-	-	SPARE
SPARE	-		20	35	36	20	-	-	SPARE
SPARE	-		20	37	38	20	-	-	SPARE
SPARE	-		20	39	40	20	-	-	SPARE
SPARE	-		20	41	42	20	-	-	SPARE
TOTAL LOAD:	4640	4640					10	0	
COMBINED LOAD:	4650	4640							

262413.L04

PANEL: 2T

VOLTAGE / PHASE: 240/120V / 1Ø

POLES: 42

KALC: 10

FED FROM: 240V SWITCHBOARD / BUILDING 4 / ROOM 158

LOCATION: BUILDING 4 / ROOM 101

MAIN BREAKER: 225A CB

BREAKER MOUNTING: BOLTED

BUS RATING: 225A AMP

LOAD DESCRIPTION	VOLT*AMP		TRIP RATING AMPS	CIRCUIT NUMBER	CIRCUIT NUMBER	TRIP RATING AMPS	VOLT*AMP		LOAD DESCRIPTION
	L1	L2					L1	L2	
RM. 126 GENERAL USE RECEPTACLE	900		20	1	2	15	10	-	POWER ON INDICATOR LGT. ON PANEL DOOR
RM. 126 FLOORBOX & TV		360	20	3	4	20	-	-	SPARE
RMS 120, 122 & 124 GENERAL USE RECEPT.	900		20	5	6	20	-	-	SPARE
RM. 124 NORTH RECEPT. WORKBENCH C2		1080	20	7	8	20	-	-	SPARE
RM. 124 SOUTH RECEPT. AT WORKBENCH C2	1080		20	9	10	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C2		1280	20	11	12	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C2	1280		20	13	14	20	-	-	SPARE
RM. 124 NORTH RECEPT. AT WORKBENCH C1	1080		20	15	16	20	-	-	SPARE
RM. 124 SOUTH RECEPT. AT WORKBENCH C1		1080	20	17	18	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C1		1280	20	19	20	20	-	-	SPARE
RM. 124 PLUGMOLD AT WORKBENCH C1	1280		20	21	22	20	-	-	SPARE
RM. 122 NORTH RECEPT. AT WORKBENCH B2	1080		20	23	24	20	-	-	SPARE
RM. 122 SOUTH RECEPT. AT WORKBENCH B2		1080	20	25	26	20	-	-	SPARE
RM. 122 PLUGMOLD AT WORKBENCH B2	1280		20	27	28	20	-	-	SPARE
RM. 122 PLUGMOLD AT WORKBENCH B2		1280	20	29	30	20	-	-	SPARE
RM. 124 TV RECEPTACLE		360	20	31	32	20	-	-	SPARE
RM. 122 TV RECEPTACLE	360		20	33	34	20	-	-	SPARE
SPARE	-		20	35	36	20	-	-	SPARE
SPARE	-		20	37	38	20	-	-	SPARE
SPARE	-		20	39	40	20	-	-	SPARE
SPARE	-		20	41	42	20	-	-	SPARE
TOTAL LOAD:	9180	7740					10	0	
COMBINED LOAD:	9190	7740							

PANEL
SCHEDULES
E-731